

# Mounting instruction Flange kit

Printed Matter No.9839 0280 00  
Publication Date 2020-01-21

Air Motors

Valid from Serial No. -

Instruction Supplement

for LZB22 Air Motors

4110098480

Product Instructions



## ⚠ WARNING

To reduce risk of injury, everyone using, installing, repairing, maintaining, changing accessories on, or working near this tool **MUST** read and understand these instructions before performing any such task.

**DO NOT DISCARD - GIVE TO USER**


**Atlas Copco**

# Table of Contents

EN    Instruction Supplement..... 3

## Instruction Supplement

### Installation



s4000502

| Ref. No. | Ordering No. | Qty | Description | Tightening torque   | Locite | Remark                             |
|----------|--------------|-----|-------------|---------------------|--------|------------------------------------|
| 1        | 4110 0984 80 | 1   | Flange kit  |                     |        |                                    |
| 2        | -            | 1   | Flange      | 50 Nm (36.9 ft-lbs) | 243    | Remove front part before assembly. |
| 3        | -            | 1   | Seal ring   |                     |        | Grease Mobil SHC Polyrex 222       |
|          |              |     |             |                     |        | Service kit:<br>4081 0038 90       |

Original instructions



**Atlas Copco Industrial  
Technique AB**  
SE-10523 STOCKHOLM  
Sweden  
Telephone: +46 8 743 95 00  
**[www.atlascopco.com](http://www.atlascopco.com)**

© Copyright 2020, Atlas Copco Industrial Technique AB. All rights reserved.  
Any unauthorized use or copying of the contents or part thereof is prohibited.  
This applies in particular to trademarks, model denominations, part numbers  
and drawings. Use only authorized parts. Any damage or malfunction caused  
by the use of unauthorized parts is not covered by Warranty or Product  
Liability.

Out of respect to wildlife and nature, our technical literature is printed on  
environmentally friendly paper.