

Mounting instruction Flange kit

Printed Matter No.9839 0282 00
Publication Date 2020-01-21

Air Motors

Valid from Serial No. -

Instruction Supplement

for LZB22-RL Air Motors

4430086180

Product Instructions



⚠ WARNING

To reduce risk of injury, everyone using, installing, repairing, maintaining, changing accessories on, or working near this tool **MUST** read and understand these instructions before performing any such task.

DO NOT DISCARD - GIVE TO USER


Atlas Copco

Table of Contents

EN Instruction Supplement..... 3

Instruction Supplement

Installation



Ref. No.	Ordering No.	Qty	Description	Tightening torque	Locite	Remark
1	4430 0861 80	1	Flange kit			
2	-	1	Flange	50 Nm (36.9 ft-lbs)	243	Remove front part before assembly.
3	-	2	Seal ring			Grease Mobil SHC Polyrex 222
						Service kit: 4081 0038 90

Original instructions



**Atlas Copco Industrial
Technique AB**
SE-10523 STOCKHOLM
Sweden
Telephone: +46 8 743 95 00
www.atlascopco.com

© Copyright 2020, Atlas Copco Industrial Technique AB. All rights reserved.
Any unauthorized use or copying of the contents or part thereof is prohibited.
This applies in particular to trademarks, model denominations, part numbers
and drawings. Use only authorized parts. Any damage or malfunction caused
by the use of unauthorized parts is not covered by Warranty or Product
Liability.

Out of respect to wildlife and nature, our technical literature is printed on
environmentally friendly paper.